

2 1
3
4

Bearing 轴承

Lead引出线 UL100

转向 CCW (风轮端或出轴端看)